

Product Information



The Log Home Care and
Maintenance Authority

Company Stores

**Washington/Western
Division**

1-800-548-1231

**Tennessee/Eastern
Division**

1-800-548-3554

Sevierville, TN

1-888-441-1116

Minnesota Branch

1-877-244-6548

Colorado Branch

1-800-433-8781

Montana Branch

1-800-479-7090

Stocking Distributors

**Canadian Log Home
Supply, Ontario**

1-800-746-7773

**Hess Log Home Supply,
PA**

1-800-257-4864

**Log Home Center &
Supply, IN**

1-800-773-6223

**Steels Industrial
Products, Ltd., B.C.**

1-877-846-7502

**Timeless Wood Care
Products, MI**

1-800-564-2987

Lifeline Advance™

Professional Exterior Clear Topcoat

Lifeline Advance is formulated to protect and extend the life of Lifeline Exterior and Lifeline Ultra-1. Lifeline Advance is thickened to make application by brush or sprayer much friendlier. It adds a soft shine to your exterior finish, while it improves water repellency and increases UV inhibitors and mildew protection on your exterior walls. Like all Lifeline finishes, Lifeline Advance breathes to allow the moisture within your logs to evaporate. Lifeline Advance is to be used as a clear topcoat over a pigmented exterior stain. It is formulated to improve performance in re-coating while allowing multiple coats for those who desire additional exterior shine.

Performance:

- Water repellent.
- UV protection.
- Mildew inhibitors.
- Extends the life of exterior Lifeline.
- Forms a breathable, clear film.
- Makes cleaning log walls easier.
- Non-yellowing.
- Adds soft luster to exterior.
- Multiple coats can be used for a deeper sheen.
- No petroleum solvents or harmful VOC's.
- Cleans up with soap and water.

Color:

Lifeline Advance is available in clear only and should not be tinted.

Coverage:

Coverage rate depends on the type of surface coated. Coverage over Lifeline Exterior or Lifeline Ultra-1 on smooth wood is up to 1000 square feet per gallon.

Packaging:

1-gallon and 5-gallon containers. Request sample to try on your wood.

Shelf Life/Temperature:

Keep container tightly sealed for up to one year. Protect from freezing and excessive heat.

Surface Preparation:

All surfaces should be clean and dry. Remove dirt and fungal growth using appropriate cleaners. Never use steel wool to clean surfaces that will be finished with a waterborne coating.

Application:

Lifeline Advance is to be applied over your Lifeline Exterior or Lifeline Ultra-1 to extend the life of your exterior finish. It is not intended for use on bare wood, because clear topcoats do not provide adequate color stabilization and long-term protection required by exterior wood surfaces. Always apply a tinted finish before using any clear topcoat. Apply Lifeline Advance after previous Lifeline has dried for at least 2 hours.

Although Lifeline Advance can be applied over an oil-based stain, we do NOT RECOMMEND it, since it will interfere with subsequent applications of oil-based products. If you still want to apply Lifeline Advance over an oil finish, wait at least 2 weeks for the oil to dry and/or penetrate into the wood.

DO NOT apply Lifeline Advance to decks or other horizontal surfaces. Apply when wood surface temperatures are between 40°F and 90°F. Best results are obtained when finish is applied in the shade.

Lifeline Advance is as easy to apply as common latex paint. Apply with sprayer or brush. When using a sprayer, be sure to brush the wet finish (back brush) to promote even coverage, eliminate runs and to ensure adequate penetration and adhesion. If you desire increased shine, additional coats of Lifeline Advance may be used. We suggest that you limit to 2 coats maximum over Lifeline Exterior or Lifeline Ultra-1 during the initial application.

Clean-up:

Normal clean up of wet Lifeline Advance requires only soap and water. If Lifeline Advance has dried, the use of mineral spirits, alcohol, ammonia or commercially available latex cleaners will help remove freshly dried finish.

Drying Time:

Apply when weather conditions allow at least 24 hours without rain. Drying time depends on temperature and relative humidity. Lifeline Advance should be dry in 30-45 minutes. Wait at least 2 hours before re-coating. Complete cure of the finish requires about 72 hours.

Frequency:

Use Lifeline Advance as needed depending on the climate and weather exposure of the finished walls.

See Lifeline Application and Maintenance Guide for more information.

visit us
online
www.permachink.com